


Correct Alignments



All hose alignments will be taken from the diagram (left) unless otherwise clearly shown on a drawing. If no alignment is stated the hose will be sent out of the factory with an alignment of 0 degrees.

Correct Measurements



The following instructions are designed to eliminate confusion and ensure that correct hose lengths are supplied for assembly. When ordering hose assemblies please make sure the following instructions are followed.

All measurements are taken from the center of seat A to the center of seat B. This will apply in all cases unless CLEAR instructions are given on purchase order or a drawing supplied.

Hose Length Tolerances

HOSE LENGTH	TOLERANCE
100mm to 200mm	± 3mm
200mm to 400mm	± 5mm
400mm to 600mm	± 6mm
600mm UPWARDS	± 1%

Standard Goodridge hose tolerances used unless otherwise stated.